



# Commercial 7x7 Zone Screen

**IMPORTANT:** Please read directions thoroughly before assembling your Zone Screen.

1. Take all parts out of the box.
2. Lay out the frame and proceed to connect all of the pieces, as shown in the diagram. Make sure all the snap connectors snap together. NOTE: You may need tools if the connectors are not snap connectors.
3. Lay out the net and slide it over the frame like a pillow case over a pillow. Pull the bottom rope tight and tie.

