

ASSEMBLY OVERVIEW

Assemble the frame on a flat, level surface.



**CIMARRON
SPORTS**
ENHANCE YOUR GAME



8'x8' Premier Zone Frame

 You may need to use a rubber mallet to fully seat some joints.

IMPORTANT:

Please read all directions thoroughly before assembly.

1

Unpack and inspect.

Lay out all frame components and confirm that each piece matches the corresponding letter in the exploded diagram.

2

Assemble the frame.

Begin assembly from the ground up as shown in the diagram. Fully seat all pipe joints before installing screws.

3

Secure all joints.

After the frame is fully assembled, install a self-drilling screw through both pipes at each connection point. No pilot hole is needed.

4

Install the net.

Slide the net over the frame like a pillowcase. Pull the bottom rope tight and securely tie it in place.

ASSEMBLY NOTES

Optional 3 piece frame padding fits as follows:

Long Piece - Top Side

Short Piece - Wheel Side

Remaining Piece - Arch Side

PARTS LIST		
A	Lower Ground 4-Way	1
B	Upper Corner Elbows	2
C	Lower Ground Legs	2
D	Single Reduced End	6
E	Double Reduced End	2
F	Wheels	1
G	Self-Drilling Screws	14
H	Drill Bit	1

